

QUICK START GUIDE

PACKAGE CONTENTS



- 1 x Upper section of Z-bracket (**A**)
- 1 x Lower section of Z-bracket (**B**)
- 1 x L-bracket with cable routing (**C**)
- 4 x M5 x 10mm screws (**D**)
- 1 x M8 x 15mm armature bolt (**E**)
- 1 x Armature washer (**F**)

STEP 1



Place the maglock into the L-bracket (**C**) as shown above.

Note: Assembly shown on a table; the L-bracket would normally be fitted to the header/transom.

STEP 2



Using the captive screws, attach the maglock to the L-bracket (**C**).

Note: We recommend applying a Threadlock solution such as Loctite to the threads of the M8 bolt to stop it loosening with use.

DO NOT USE STUD LOCK, as this will not allow removal without heat application.

STEP 3



Remove the end covers from the lower section of the Z-bracket (**B**).

STEP 4



Slide the cover off the bracket (**B**).

STEP 5


Position the two parts of the Z-bracket (**A** & **B**) as shown, allowing for any adjustment needed for door/frame spacing.

STEP 6


Secure the two sections of the Z-bracket (**A** & **B**) using the four screws (**D**).

STEP 7


Z-bracket assembly complete.

STEP 8


Slide the cover back into place.

Note: The Z-bracket would normally be fitted to the door face; it is shown on a desk for clarity.

STEP 9


Refit the end covers.

STEP 10


Locate maglock armature and fixing accessories:

- 1 x M8 x 15mm Armature bolt (**E**)
- 1 x Armature washer (**F**)

STEP 11


Insert the bolt (**E**) through the armature plate and fit the washer (**F**) on the opposite side as shown. The washer is essential to allow the armature to self-align with the magnet face.

STEP 12


Once again, we highly recommend applying a Threadlock solution, such as Loctite, to the threads of the M8 bolt to prevent loosening during use.

STEP 13


Install the armature plate assembly onto the Z-bracket as shown. Tighten the bolt (**E**) securely but ensure it still allows movement against the washer (**F**) for self-alignment. Otherwise, full holding force will not be achieved.

STEP 14


Close the door to make sure everything lines up as per the two images shown above.

Note: The images show the lock and brackets on a desk for ease of viewing.