Settings Note

1. Click ⊕ or ⊖ to switch between 2.8 mm and 4 mm lenses.

2. Click ⬚, or ⬚, or ⬚ on the web page to make the image clear after installation.


```
PTZ

        ▲
   ◄   ⏻   ►
        ▼

SLOW              FAST

Zoom ···(Q Q)   (⬚⬚) ···· Focus

           ⬚· ···· Auxiliary
                    Focus
```

Note: Take the actual functions as the standard.